

DB739-A Large Dial

Parts

This Large Dial covers the existing turret of 4.5x-28x52mm.



How to fit the large dial

1. First rotate the elevation turret so that the "0 (zero)" faces forward and align with the index line. Cover the large dial on top of the existing turret.

Please match the 3 holes without the screw of the large dial with the 3 screws of the existing turret underneath the large dial.



2. Lock the 3 screws of the large dial using Allen wrench.
Please note that by fastening the screws of the large dial, It may leave a scratch on the elevation turret underneath.



3. Loosen the screws of the elevation turret through 3 holes without the screw of the large dial. Turret will then move loosely.
4. Align the "0(zero)" of the large dial with the index line.
Then fasten the screw which was loosened in section 3.
5. If you wish to re-zero your scope, please set the zero by carrying out 3 and 4 explained above.



Now you have completed fitting the large dial.

