

How to set 0-set dial on 8x-80x Majesta

1. Unlock the dial lock



2. Turn the dial to the position to set 0-set.



3. Turn 0-set in the direction of the arrow (counterclockwise).



4. Screw in until 0-set stops.



5. You are done.

